# Public-Private Partnerships "P3" Transportation Projects




# What is a P3?

- An agreement between public and private sector partners which allows more private sector participation than is traditional:
  - Private sector may design, construct, finance, operate, maintain, renovate and / or manage a facility or system
  - Public sector usually "owns" the asset and leases it to the private section
  - Sharing of roles, responsibilities, risks and rewards
  - Possibility of Private Sector equity

# **Types of P3s**

- Design-Build (DB)
- Asset Management Contract
- Design-Build-Operate-Maintain (DBOM)
- Design-Build-Finance-Operate (DBFO)
- Build-Operate-Transfer (BOT)
- Build-Transfer-Operate (BTO)
- Joint Development Agreement (JDA)
- Concession
- Asset Lease/Sale



### **Background of P3s**

- "Privately" provided transportation was first and foremost in the US beginning in the 1800s lasting into the early and mid 1900s
  - Rail Systems private, but regulation evolved
  - Development/Toll Roads private (50k miles), then public
  - Public Transit Systems private, then public
  - Airlines private, but regulation evolved

# **Background of P3s (cont)**

- Government role grew dramatically early to mid 1900s in U.S., taking over many former private responsibilities
- "Privatization" was the buzzword in the 80s and early 90s in Europe, New Zealand, etc.
  - Rail Systems
  - Aviation Systems
  - Highways/Toll Roads
  - Water/Sewer
  - Others

### Past 20 plus Years "P3s" in U.S.

- Outsourcing Partnerships in Government
  - Construction
  - Engineering (varies greatly by govt. entity)
  - Operations and Maintenance (varies)
- Periodic private sector "equity"
  - Land donations very common
  - Partial or Full Cash investment expressway interchanges

#### P3s in Europe and Canada

- Moved from Privatization to P3s and PFIs in 1990s and 2000s; "partnership" is essential:
  - Long-Term Agreements
  - Proper Roles for both Partners
  - Infrastructure Essential to the Economy Must be Operated Efficiently, Adequately Maintained
  - Compensation Must be Fair to Both Partners
  - Must Deal with Expansions

### **Characteristics of a P3**

- Project Champion
- Longer-Term Agreements
- Private sector funding (equity and debt)
- Private sector operates multiple major project elements (design-build, plus operatemaintain, etc.)
- Sharing of risk between private sector and public owner

#### What are the Benefits of P3?


- Accelerate High Profile Projects
- Economic Stimulus/Jobs
- Private Sector Expertise
- Use "Others" Money
- Promote Innovation in Project
   Development and Delivery Profit
   Motive

# What is Driving P3s?

- "Needs" far outweigh available resources
- Government purchasing power is eroding
- Cost certainty
- Changing financial markets/tools
- Legal authority for P3 opened up
- Ability to use user fees more acceptable
- Bottom line P3 can advance projects

# **States with P3 Legal Authority**

(source - US DOT)



12/5/2013

Clary Consulting, LLC

#### **Facts vs. Fiction**

- P3s increase funding for government?
- All P3s led by foreign firms?
- P3s "take away" work from U.S. based firms?
- P3s will replace "traditional" project delivery approaches?
- You need a PHD in P3s to understand this new tool?
- Expert advisors are essential for success?

#### **Environment for Success**

- Outside the Box Thinking
- Political Support
- Project Champions
- Understanding/willingness to take risk
- P3 "owner" processes
- Select the right projects

#### **Uses Other People's Money**

- Private equity partners, several types:
  - Developer, higher risk, generally first money in and first money out – lose it all or larger return
  - Equity partner, covers riskier time of project, generally early years
  - Longer-Term Equity Partner patient investor
- Lenders, much like typical mortgage/bond financing from banks and public bond market

#### **Private Sector Funding**

- "Skin in the Game" meaning the private sector puts funding into the project - Equity funding that is at risk, not just debt
- Many areas of "at risk" examples:
  - Cost/schedule guarantees where the private firm must cover all or selected overruns and/or delays;
  - shortfalls in estimated user fees;
  - Asset availability, with payment reductions if the facility is not open to use

# Why is Private Equity Critical?

- Traditional approaches for government debt have been damaged by financial crisis
  - Bond Insurance all but gone
  - Need for stronger credit structures, cutting ability for 100 percent project debt financing
- Private equity strengths
  - At risk funding focused on success
  - Subordinated to project debt "coverage factor"
  - Private firms delivering the project invest in effort

# **Risk Considerations**

- P3s are about allocating and managing risk
- There must be key people with the ability and "stomach" to analyze risk, discuss it with the private teams and make decisions that protect the public interest while ensuring the private teams are treated fairly
- These are "big decisions" that can mean millions of dollars in future savings or higher cost depending on the outcome

## **Sharing of Risk**

- The sharing of risk is a key benefit of P3s.
- The key is to balance the risk to the partner that can best manage/mitigate the risk.
  - Design/Construction private
  - Environmental Clearances public
  - Permits generally shared, but project specific
  - Right-of-Way generally public, but can be private
  - Operations/Maintenance private or public, depending on the goals of the project

# **Term of Agreements**

- Some early P3s were too short and there was not adequate time for the private entity to recoup their investment
- A term "financial equilibrium" developed that helps define the point where the private sector and public sector financial interest intersect
- Led to longer-term P3s, generally 20 years and longer

### **P3 Compared to Public**

- Independent Studies on varied types of government and P3 projects in U.K. and Australia
  - PPP projects normally delivered on time and within budget
  - Traditional projects normally late and significantly over budget
  - 2008 Australia study on completed projects
    - \$4.9B in PPP, overrun 1.2%, ahead of schedule
      3.4%
    - \$4.5B in Traditional, overrun 15%, behind schedule 23.5%

# "Types" of P3s in Transportation

#### • Lease of Existing Asset

 Asset "Owner" leases the facility such as toll road for extended term for payment from private entity

#### • Availability Payment

 Private entity provides DBFOM receives periodic payment from "Owner" for availability of facility

#### • Revenue Risk

- Private entity provides DBFOM and assumes risk of revenue stream (usually tolls) for payment
- Developer CDD Type Approach

### **Major P3 Project Examples**

- Leases of Existing Assets (Toll Facilities) Examples:
  - Chicago Skyway raised \$1.8 billion (www.chicagoskyway.org)
  - Indiana Turnpike raised \$3.8 billion (www.getizoom.com)
  - Pocahontas Parkway to restructure a challenged financial situation (www.pocahontas895.com)
  - PR-22 and PR-5 Puerto Rico raised \$1.4 billion (www.p3.gov.pr/?page\_id=119?page\_id=925&lang=en)

# Major P3 Project Examples (cont)

- Availability Payment Project examples:
  - Port of Miami Tunnel (www.portofmiamitunnel.com)
  - I-595 FL (www.i-595.com)
  - Eagle P3 Denver Commuter Rail (www.rtdfastracks.com/main\_126)
  - Presidio Parkway CA (presidioparkway.org/contractors/publicprivate\_partnershi p\_overview.aspx)
  - Windsor-Essex Parkway ON

(www.infrastructureontario.ca/What-We-Do/Projects/Project-Profiles/The-Windsor-Essex-Parkway)

# Major P3 Project Examples (cont)

- Revenue Risk Project Examples
  - I-495 VA DC area Hotlines (www.vamegaprojects.com/ about-megaprojects/i495-hot-lanes/)
  - North Tarrant Express TX (www.txdot.gov/project\_information/projects/fort\_worth/ north\_tarrant\_express/default.htm)
  - LBJ Managed Lanes TX (www.newlbj.com/default.asp?p=1)
  - South Bay Expressway CA (www.southbayexpressway.com/)

### **Partnering with Growth**

- Development Driven
  - Over 200 "development districts"
  - Numerous community redevelopment areas
  - Tax Increment financing common
  - Impact Fees and Related Fees
  - Developer contributions and partnerships
- Total amount generated not easy to discern likely billions for infrastructure improvements

#### **Design-Build-Finance**

- Tool to advance medium to large projects when funds are spread over time
- Private Team borrows the "gap" needed to advance the project and is paid back over time
- Florida DOT has advanced eleven projects between 3 to 6 years totaling over \$2.4 billion
- All projects were at or below the estimated cost and available funding.

# **Design-Build-Finance**

- Traditional Design-Build adds gap financing by the design-build team – IROX I-75 and I-75 Caloosahatchee Bridge in Southwest Florida, I-4 Crosstown Connector in Tampa Bay
- Generally used for "medium size to large" projects - \$50M to \$500M or larger
- Banks loans are debts of the contractor and creates issues with Surety
- New Bond Approach tax-exempt bonds, open to Surety and not a debt of contractor

#### Landowner Developed Toll Road

- New Toll Technology eliminates "cash toll booths" and allows tolls on any roadway
- Several arterial roadways being developed as toll roads
- Tallahassee example Orchard Pond Greenway
- Landowner equity of land and studies
- State supporting via FDOT State Infrastructure Bank Loan

#### **State Infrastructure Bank**

- Implemented in Florida in 1997. Two "Accounts" for the Florida SIB:
  - Federal Account projects must meet Federal highway and transit program criteria:
    - \$352 million in loans supported \$1.15 billion in projects

- State Account - all transportation modes eligible:

- \$753 million in loans supported \$7.2 billion in projects
- Bonded the repayment stream portfolio
- Flexible repayment terms and can be subordinate to senior debt

#### **Private Sector Expertise**

- Bottom Line Leads to Innovation
- Linking DB Saves Time, Sometimes Cost too
- Long-Term O&M Drives Quality DB
- Excellent Financial Modeling
- Lenders Watch Private Team Closely same interest as owner
  - Closely examine technical/financial plans
  - Approve DB progress payments
  - Make sure asset is properly maintained

# Fad or Long-Term Trend?

- Needs are not going away
- Stresses on funding sources in government
- P3 market well developed internationally
- Further consolidation of U.S. construction industry with increasing foreign ownership
- Major capital raised for P3 market
- Success breeds further P3s

#### Questions

#### Lowell Clary, President – Clary Consulting, LLC – Lowell.clary@claryconsulting.com – 850-212-7772 – www.claryconsulting.com